



EUCLID CHEMICAL

CHEMICAL-URETHANE GROUTS

DURAL PUMP RINSE

MASTER FORMAT #:
1 1 01 20

DURAL PUMP RINSE

URETHANE GROUT INJECTION PUMP CLEANER/PRIMER

DESCRIPTION

DURAL PUMP RINSE is a non-flammable, solvent-free fluid used to clean out the lines of polyurethane grout injection equipment. DURAL PUMP RINSE can also be left in the pump lines as a primer.

PRIMARY APPLICATIONS

- Injection pump cleaner
- Priming lines of injection pumps

FEATURES/BENEFITS

- Non-flammable, non-corrosive
- Contains no solvents
- Thoroughly cleans urethane grouting equipment, ensuring a moisture-free injection system

TECHNICAL INFORMATION

TYPICAL PROPERTIES	RESULT
Specific Gravity @ 77°F (25°C)	0.96
Viscosity @ 77°F (25°C)	122 cps
Flash Point	450°F (232°C)

PACKAGING

DURAL PUMP RINSE is packaged in 5 gallon (18.9 L) pails.

SHELF LIFE

3 years in original, unopened containers.

DIRECTIONS FOR USE

Pour DURAL PUMP RINSE into both A side and B side pump tanks. Use a scrubbrush to remove any grout residue from the sides or bottom of tanks. Dispense The DURAL PUMP RINSE through hoses into an appropriate waste receptacle. Add clean DURAL PUMP RINSE into the pump and prime the lines, leaving the DURAL PUMP RINSE in the pump until the next project. Be sure to expel all DURAL PUMP RINSE from the lines prior to the next grouting job, because remaining material will affect the curing capability of urethane grouts.

PRECAUTIONS/LIMITATIONS

- In all cases, consult the Safety Data Sheet before use.

Rev. 02.17

WARRANTY: The Euclid Chemical Company ("Euclid") solely and expressly warrants that its products shall be free from defects in materials and workmanship for one (1) year from the date of purchase. Unless authorized in writing by an officer of Euclid, no other representations or statements made by Euclid or its representatives, in writing or orally, shall alter this warranty. EUCLID MAKES NO WARRANTIES, IMPLIED OR OTHERWISE, AS TO THE MERCHANTABILITY OR FITNESS FOR ORDINARY OR PARTICULAR PURPOSES OF ITS PRODUCTS AND EXCLUDES THE SAME. If any Euclid product fails to conform with this warranty, Euclid will replace the product at no cost to Buyer. Replacement of any product shall be the sole and exclusive remedy available and buyer shall have no claim for incidental or consequential damages. Any warranty claim must be made within one (1) year from the date of the claimed breach. Euclid does not authorize anyone on its behalf to make any written or oral statements which in any way alter Euclid's installation information or instructions in its product literature or on its packaging labels. Any installation of Euclid products which fails to conform with such installation information or instructions shall void this warranty. Product demonstrations, if any, are done for illustrative purposes only and do not constitute a warranty or warranty alteration of any kind. Buyer shall be solely responsible for determining the suitability of Euclid's products for the Buyer's intended purposes.